



Installation Instructions for the Metropolitan Pedestal

Items needed for Installation:

- A quality 100% clear silicon adhesive.
 - Phillips Tip Screwdriver
 - Level
 - Pencil
 - Tape Measure
-

Directions:

- On the installation wall, measure 30 ¾" from the finished floor height and mark with your pencil. Use level to scribe a horizontal line approx. 12". Place angle (#6) against the wall with the top of the angle level with your line. Use pencil to mark fastener holes through angle to wall. Remove angle and install wall anchors (package F) where marked. Anchors should be flush with wall surface. Install angle to wall with screws.
- Place legs (#1) on a flat protective surface with the front face down. Place lower shelf (#3) ends into legs and install fasteners (package E).
- Slide arch top support (#2) into place and install fasteners (package A).
- Use fasteners (package C) to attach support (4) to wall mount adapter (5) through the countersunk holes.
- Place support (#4) onto shelf (#3) as shown in figure and install attaching screw (package D) until tight.
- Place stand vertical with wall mount (#5) against wall surface and center on wall angle. Place level on shelf running from front to back. Level shelf and mark wall fasteners holes through wall mount adapter (#5). Install wall inserts from package B. Add fasteners through adapter to mount to wall.
- Add a bead of silicone sealant to the top of the arch support and the wall angle as per view G.
- Place pedestal slab on top of wall angle and arch support and center. Wipe any excess sealer from pedestal. Use silicone adhesive to attach backsplash to wall. Wait for 12 hours sealant to cure before installing sink.

Any questions with the installation, please call Customer Service at
(877) 322-3600. We will be happy to assist you.