

Installation Instructions For Your Lautus Natural Stone Under mount Sink

Models CR-R4015-UC, DE-R4015-UC, BM-R4015-UC, TS-R4015-UC

Please read all instructions thoroughly before proceeding!

Items needed for Installation:

- A quality 100% clear silicone adhesive sealer.
- Plumbing tailpiece designed for Vessel sinks. (D'Vontz model # PU-4412) for more information, go to www.dvontz.com/drains
- Soft cotton rag.

Directions:

- Carefully unpack components taking special precautions not to chip edges or drop sink or slab. Handle the countertop slab with care. Handling slab in a vertical position will help prevent possible fracturing of slab.
- A flat non-abrasive surface should be located to support the slab for sink attachment. Gently position slab with top facing down and bottom facing up, pre-set fasteners will be exposed upward.
- A circle with alignment marks has been drawn in order to aid in proper alignment of sink to slab.
- Bonding surface of slab (just inside circle) should be free of dust and dirt. Bonding surface of sink (rim) should be free of dust and dirt.
- Apply a continuous bead of silicon sealant onto the countertop slab just inside of the alignment circle. (See figure 1-B) Carefully set sink onto slab being careful to align sink with circle. **Install sink with overflow hole aligned with index mark.** Add silicone sealer to gap between sink and slab. (See figure 1-C)
- Install the clip, washer and wing nut. (See figure 1-D) Tighten the wing nuts enough to hold the sink in place. **Do Not Over Tighten!**



Fig. 1-B



Fig. 1-C



Fig. 1-D

- Check for any excess sealant that may have been squeezed to the inside of bowl. Remove with soft cotton rag. **Allow an hour of set time for sealant before installing on cabinet.**
- Cabinet instructions should be followed at this point prior to setting assembled slab and sink.
- After installing cabinet, silicone adhesive should be applied between cabinet corners and slab to attach countertop to cabinet.
- Carefully support sink and slab, set onto cabinet frame and align with cabinet.
- **Please note drain tailpiece must be designed for use with Lautus Undercounter marble sinks.**
- Install tailpiece drain - remove the mounting nut and rubber beveled washer from tailpiece drain. If tailpiece came with a thin rubber washer for mounting under flange, please discard.
- Apply a bead of silicone sealer under the mounting flange of the tailpiece and position into the drain hole of the Vessel. **Do not use plumbers putty under the flange for this may damage or discolor stone.** Work into place by slowly pressing the tailpiece until it seats against sink. You should have a small amount of sealer squeezing out between the tailpiece flange and sink.
- While holding the tailpiece in place, slide the beveled rubber washer onto the tailpiece beveled side up. Follow with metal washer (if provided) and mounting nut.
- Tighten mounting nut. Nut torque just needs to be enough to seat tailpiece flange firmly into Vessel. Do not over tighten. Remove any excess sealer inside the Vessel with a soft cotton rag.
- Connect overflow tube to drain tailpiece. Tube may need to be trimmed at this point for proper fit.

- Your sink is now installed and ready for the drain trap to complete the drain installation.
- Backsplash should be mounted with silicone adhesive. Apply to back of marble and then firmly press against wall.

Any questions with the installation of your new Lautus Marble Undercounter Sink, please call us at (877) 322-3600. We will be happy to assist you.



Copyrights 2005 D'Vontz L.L.C.